


Models 6-S-254, 6-S-256 (5644 Chassis)



ITEM NO.	DESCRIPTION	ITEM NO.	DESCRIPTION
C.1	22-327 PHONO INPUT COIL	22-327	PHONO INPUT COIL
C.2	22-401 0.5 MFD	22-401	0.5 MFD
C.3	22-549 DUAL FIXED PADDER	22-549	DUAL FIXED PADDER
C.4	22-427 2.5 MHZO	22-427	2.5 MHZO
C.5	22-700 1 MHZO	22-700	1 MHZO
C.6	22-829 0.5 MHZO	22-829	0.5 MHZO
C.7	22-857 0.2 MHZO	22-857	0.2 MHZO
C.8	22-182 00025 MHZO	22-182	00025 MHZO
C.9	22-182 00015 MHZO	22-182	00015 MHZO
C.10	22-162 0001 MHZO	22-162	0001 MHZO
C.11	22-447 00005 MHZO	22-447	00005 MHZO
C.12	22-326 0005 MHZO	22-326	0005 MHZO
C.13	22-189 01 MHZO	22-189	01 MHZO
C.14	22-100 1 MHZO	22-100	1 MHZO
C.15	22-646 004 MHZO	22-646	004 MHZO
C.16	22-433 08 MHZO	22-433	08 MHZO
C.17	22-486 002 MHZO	22-486	002 MHZO
C.18	22-551 1MHZ ELECTRO COIL	22-551	1MHZ ELECTRO COIL
C.19	22-558 10MHZ ELECTRO COIL	22-558	10MHZ ELECTRO COIL
R.1	63-533 6700 MH	A	VARIABLE TUNING
R.2	63-537 4000 MH	B	1ST TUNING PRIMARY
R.3	63-680 1000 MH	C	1ST TUNING SECONDARY
R.4	63-677 33 MH	D	2ND TUNING PRIMARY
R.5	63-271 1 MH	E	2ND TUNING SECONDARY
R.6	63-625 1000 MH	F	WAVE TRAP
R.7	63-650 330 MH	G	BROADCAST OSCIL (SEE NOTE)
R.8	63-739 2.4 MHZ BAND VOLUME CONTROL	H	ANTENNA BROADCAST (ON SWING)
R.9	63-236 220 MH	I	BROADCAST PADDER
R.10	63-537 470 MH	J	SHORT WAVE OSCIL (SEE NOTE)
R.11	63-325 150 MH	K	SHOR WAVE DETECTOR
R.12	63-613 3 SECTION CANDOT	L	POLICE BAND OSCIL (SEE NOTE)
1	20-154 WAVE TRAP ASS'LY	M	NOTE:
2	3-5073 ANT COIL SHIELD ASS'LY	N	TRIMMERS F-K-N
3	3-5076 OSCIL COIL & SHIELD ASS'LY	O	MAINTAINED ON BATTALITE
4	95-416 1ST IF TRANSFORMER	P	37 PIP PART NO 22-324
5	95-114 BAND SELECTOR SWITCH		
6	95-114 BAND SELECTOR SWITCH		
7	95-114 POWER TRANS. 117V 50 CYCLES		
8	95-154 POWER TRANS. 117V 50 CYCLES		
9	95-154 POWER TRANS. 117V 50 CYCLES		
10	95-154 POWER TRANS. 117V 50 CYCLES		

SPEAKERS **MODELS**
 49-208-10" 6-S-254
 29-101-10" 6-S-256

ZENITH RADIO CORPORATION